1.IR Remote control

- 1 Turn off
- 3 Brightness +
- (5) Color Temperature -
- (7) Brightness -
- 9 Warm White
- (11) Night Light Mode

- 2 Turn on
- (4) Change colour temperature
- (6) Color Temperature +
- (8) Cold White
- (10) Natural White
- (12) Auto turn off after 30 Mins

